## **Updating C**

- Unzip the archive with the new code.
- The folder containing the code, e.g. 'C-11-04' should be placed in the folder "...\cc\code".
- Open the file "cc\_localsettings.sdv" that is found in the C root folder and update the version to the folder name of the code. The part to be edited is shown in blue in the example below.
- Note that it is not necessary to delete the folders with old code. Keeping these allow you to run previous versions if necessary.

An example of "cc\_localsettings.sdv" is shown below. Parts to check or edit is shown in blue.

```
version;C-11-04;Current version and name of subdirectory for
codes
defaultmethod;Default;Method to load on start
windowpos;[0 0.06 1 0.9];Position and size of main window
path_agilent;C:\GC-MS-Data;
path_cdf;C:\GC-MS-Data;
path_csv;C:\cc\agilent-csv;
path_matlab;C:\MATLAB6p5\work;
path_prs;C:\MATLAB6p5\prs;
tracker;0;
editor;notepad;Text editor for txt files ('notepad'/'default')
Notepad or win default
```